

CLEANING AND MAINTENANCE GUIDE

BENCHES — COUNTERTOPS AND VANITIES — TABLES — SHELVES AND WINDOWSILLS

This guide is intended for owners of EAD Design's SURFACE products. A copy of this guide should be provided to all maintenance and cleaning staff.

Our warranty does NOT cover damage caused by poor maintenance or failure to comply with this guide's cleaning and maintenance instructions. Should you have any questions regarding the warranty or cleaning/maintenance instructions, please contact your EAD Design representative.

BENCHES - COUNTERTOPS AND VANITIES - TABLES - SHELVES AND WINDOWSILLS

Surfaces can be easily cleaned using a soft, lightly dampened cloth and a neutral detergent or cleaning product. Rinse using warm water.

Do NOT apply cleaning products or detergents directly on surface.

For stubborn stains, make a paste using baking soda and water. Apply paste to stain using a soft bristle brush. Lightly brush paste onto surface in a circular motion. Rinse using warm water and wipe using a soft cloth.

10 to 20 circular rotations should suffice; excessive rubbing can cause friction and damage the surface.

Caution:

- Even mild and neutral detergents are susceptible to leaving **a film or residue** that can damage the surface and its appearance.
- Do NOT use **abrasive** or **acidic** products or detergents.
- To fix or reduce the appearance of **scratches**, use a sealant or corrector pen. Do NOT use a permanent marker.

CONTACT WITH WATER

To preserve the integrality of the material, replace sealing joints for all SURFACE products where sealing joints might be in contact with water.